

# **LED Cyclorama**

# GTD-L3100

# **User's Manual**

Guangzhou GTD Lighting Technology Co., Ltd.

Tel: +86-20-61808296 Fax: +86-20-61812282 http://www.gtd-lighting.com



©2017 GTD all rights reserved. Information, specifications, diagrams, images, and instructions herein are subject to change without notice. GTD logo and identifying product names and numbers herein are trademarks of GTD. Copyright protection claimed includes all forms and matters of copyrightable materials and information now allowed by statutory or judicial law or hereinafter granted. Product names used in this document may be trademarks or registered trademarks of their respective companies and are hereby acknowledged. All non-GTD brands and product names are trademarks or registered trademarks of their respective companies.

GTD and all affiliated companies hereby disclaim any and all liabilities for property, equipment, building, and electrical damages, injuries to any persons, and direct or indirect economic loss associated with the use or reliance of any information contained within this document, and/or as a result of the improper, unsafe, insufficient and negligent assembly, installation, rigging, and operation of this product.

Guangzhou GTD Lighting Technology Co., Ltd. | 27 Fu Yuan Yi Road, Guangzhou 510805, P.R.China +86-20-61808296 | +86-20-61812282 fax | <u>www.gtd-lighting.com</u> | <u>contact@gtd-china.com</u>



# Contents

Safety instructions	3
General guidelines	4
Packing and shipping	5
Unpacking	5
Packing after use	5
Accessories	5
Product introduction	6
Installation	7
Clamps installation	7
Device installation	7
Power / Control connection	7
Power connection	7
Control connection	8
Testing	8
Control panel	9
Menu structure	10
DMX protocol 1	11
Technical specification	13
Cleaning and maintenance 1	14
Troubleshooting	٤5
System wiring diagram 1	16
Spare parts list	17
Appendix 1 1	17



## Safety instructions

<b>^</b>	WARNING!
	Before using the fixture, read the latest version of the product user manual, paying particular attention to the safety instructions. Please check <u>www.gtd-lighting.com</u> for the latest revision/update of the user manual. The manufacture of this fixture, are not responsible for damages, resulting from misuse of this fixture, due to the disregard of the information printed in this user manual.
	DANGER! Hazardous voltage. Risk of lethal or severe electric shock.
	WARNING! Burn hazard. Hot surface. Do not touch.
	WARNING! Fire hazard.
	INDOORS USE ONLY! Do not expose fixture for rain and moisture.
	It's essential that the fixture is properly grounded. Only qualified personnel should perform electrical connections.
	WARNING! Wear protective eyewear. Never look directly into the light source.
	lified and certified personnel should perform installation of this fixture and only the original rigging parts ) included with this fixture should be used for installation.

- Before applying power to the fixture, check that the source voltage matches the fixture's requirement. Every fixture must be earthed (grounded) and installed in accordance with local electricity regulations. Do not connect it to a dimmer system.
- Never look directly into the light source of this fixture to prevent risk of injury to your retina, which may induce blindness.



## **General guidelines**

- Never open this fixture while in use.
- The fixture should be kept clean. **DO NOT** operate the fixture in extreme heat or dusty environments. Avoid contact with chemical liquid.
- This fixture is a professional light effect designed for INDOOR / DRY LOCATIONS ONLY on stage, in nightclubs, theatres, etc.
- Minimum distance to lighted objects must be 3.28feet (1m).
- Maximum temp of the external surface 140°F (60°C).
- Maximum ambient temperature 113°F (45°C).
- Minimum distance of inflammable materials from the surface 1.6 feet (0.5m).
- LED lamp should be changed if damaged or distorted in shape due to extreme heat.
- Cover, lens or Menu Function Display with visible damages such as cracks or scratches must be replaced to ensure performance of the fixture.
- Disconnect the fixture from power before changing any parts or accessories.
- Make sure that the installation area can hold a minimum point load of 10 times the weight of all installed fixtures, clamps, cables, auxiliary equipment, etc. Check that the cover, clamps and locks are undamaged. Certified safety cables must always be used when installing the fixture.
- The fixture is only intended for installation, operation and maintenance by qualified professional. Instructions stated in the manual must be complied.
- The fixture must be kept in a well-ventilated place at least 50 cm away from any wall surface. Check if the fans or ventilation openings are unblocked.
- Broken or damaged cables can only be fixed or changed by certified technicians, certified local distributors or the manufacturer to ensure operational safety.
- Do not stick filters or other materials onto the lens. Do not modify the fixture or install other than GTD manufactured parts.
- For questions regarding safety operation, please contact our technical personnel or call the service hotline +8620 61808296.



## Packing and shipping

### Unpacking

## ▲Notes

All products are quality controlled and checked for any faults before they are dispatched to customers. If the fixture is damaged during delivery, the customer must notify the shipper and manufacturer to file a damage insurance claim. Photographic evidence of the damage must be provided.

#### Flight-Case

Open the cover of the flight-case and remove the plastic packing bags. Hold the handles of the fixture firmly and take it out carefully.

#### Cardboard box

Open the box and take out the whole set of packaging foam which contains both the fixture and its accessories. Remove the foam from the top, put away the accessories, and then take out the fixture wrapped in the plastic bag.

#### Packing after use


- 1. Switch off the fixture and wait for at least 5 minutes before disconnecting it from AC power. Cool down the fixture for at least 15 minutes before packing.
- Flight case: Wrap the fixture in plastic bags. Hold it by the handles, and then carefully place it inside the flight case along with all the accessories. Close the cover. Do not upside down.
   Cardboard box: Wrap the fixture in plastic bags. Put it in the packaging foam along with all the accessories. Place the other set of packaging foam on top then carefully put it inside the cardboard box.

## Accessories

Item	Qty	Unit	Notes
User Manual	1	рс	-
Clamp	1	set	Ø42-52mm, Max. 200 kg
Power cable	1	рс	


## ANotes

Accessories are subject to change without any prior written notice.





## **Product introduction**



Hanging on the truss



## Installation

## **Clamps installation**


The fixture can be placed on the stage or mounted on the truss facing any direction. Attach the clamp to the mounting position on the base of the fixture.

## Warning

Use one clamp when mounting the fixture. Fasten the screw properly and connect a safety cable to fixture.

### **Device installation**

- 1. Make sure there is no damage on the clamps or safety cables before installation.
- 2. The clamp is mounted on the holder of the fixture. Horizontally insert the clamp into the mounting holes of the base. Fasten the clamp tightly.



Placed on the floor

## **Power/ Control connection**

#### **Power connection**


Connection method:

- L (Live) Brown wire
- E (Earth) Yellow / Green bi-color wire
- N (Neutral) Blue wire
- The voltage and frequency of the power source must be in compliance with the ones marked on the fixture. Please apply series connection when many sets of fixtures are connected to the power source to avoid heavy load to the power source. When the voltage is 110V, maximum 4 sets of fixtures could be allowed in each series connection. When the voltage is 220V, maximum 8 sets of fixtures could be allowed in each series connection. Another series connection should be set up for extra fixtures.

## ▲Notes


It is essential that each fixture is correctly grounded and the electrical installation conforms to all relevant Standards / Codes of Practice for Safe Electrical Work.






## **Control connection**

The fixture has 5-pin XLR connectors for DMX data input and output (3-pin optional) as shown below. Connection between the console and fixture, and between fixtures must be made with 2 core screened DMX signal cable. Maximum connecting distance of signal cable is 150 meters. Additional DMX512 signal-amplifier is recommended for longer distance.



Connect the Console's DMX OUTPUT to the first fixture's DMX INPUT, then the first fixture's DMX OUTPUT to the second fixture's DMX INPUT and so on. It is recommended not to connect more than 32 units on a single DMX universe. On the last fixture's output connect a DMX terminator. (The terminator is a XLR connector with a  $\frac{1}{4}$  W and 120 $\Omega$  resistor between the pin 2 and pin 3) as shown below:




## Testing

Connect the fixture to AC power. Check if the LED lamp is on and the fixture is independently controllable before putting into operation.





## **Control panel**



- The control panel with buttons and digital display can access the function menu and configure the fixture easily.
- Press MENU to check or modify the functions of the fixture; Press UP or DOWN to view or select the function menu.
- Press ENTER to choose a function and enter into corresponding sub menu. Each menu represents a specific function of the fixture.
- Press ENTER to select the specific function and save the changes or enter into the submenu, then press UP or DOWN to change the value of the selected function (increase or decrease).
- Press MENU to return to the previous menu or exit.
- LED indicators:
  - Power on: RED power LED indicator on
  - Signal on: Green DMX indicator on
  - No Signal: Green DMX indicator off



## Menu structure

L3100 - Menu Structure				
Revision: A	Valid from firmware version: 1.0			

Level 1	Level 2	Level 3	Level 4	Info
Rddr	Rxxx ROO!			Setting the DMX address
	rUN	NStr/ALON		Running build-in program as the master or the slave
PLAY	RUJI	NStr/ALON		Receiving soundsignal as the master or the slave
	RUEO	CLOS/HOLd/RUEO/RUdl		Setting the status when no DMX signal received
FINE	on			Standard channel mode
	OFF			Basic channel mode
n ic	N-xx N-72			Adjusting the sensitivity of Microphone
d ISP	UALU	d-xx d-00 (dxxx)		Display the channel value
	900	ON/OFF		Turn on or off the Backlight time function
	Egga	00/ <b>0FF</b>		Inverted Display
	r dNH	ON/OFF		Allow the console to change the Address
	dEFR	ON/DEE		Factory reset
SEF	FROS	RUEO/H ISH/LOU		Setting the Fans' status
	SRUE	0FF/ ( -99N <b>  5N</b>		Close the LED light when no signal
	UEr	U1.0~U9.9		Software version
	SEPr	RUEO IPO1~IP10		Selecting the program that want to edit
	SEEP	S-01 ~ <mark>5-48</mark>		Setting the steppes of program
		C-01-C-xx	XXX( <b>0~255</b> )	Editing program by manual
Ealf	SCxx	FIUE	<u>T</u> XXX( <b>001 ~999</b> )	Running time
		CEdt	OR/ DFF	Receiving build-in program from console or not
	rEC.	rE.xx		Recording senses automatically
	-00	ON/ OFF		Program test

## ▲Notes

Settings highlighted in light grey are default values.



# DMX protocol

L3100 - DMX Protocol												
Revision: A					Valid f	rom firm	ware version: 1.0					
DMX Standard (21ch)	mode Basic (12ch)	Name	DMX value		DMX value		Name DMX value			MX entage	Function	Default DMX Value
(,	()		0	31	0.0%	12.2%	Closed					
			32	63	12.5%	24.7%	Open					
			64	127	25.1%	49.8%	Synchronous strobe from slow to fast					
1	1	Strobe/Shutter	128	159	50.2%	62.4%	Open	0(0%)				
			160	223	62.7%	87.5%	Random strobe from slow to fast					
			224	255	87.8%	100.0%	Open					
2	2		0	255	0.0%	100.0%	No light $\rightarrow$ Full light					
3		Intensity	0	65535	0.0%	100.0%	Intensity fade, fine (LSB)	0(0%)				
4	3		0	255	0.0%	100.0%	No light $\rightarrow$ Full red					
5		Red	0	65535	0.0%	100.0%	Red, fine (LSB)	0(0%)				
6	4		0	255	0.0%	100.0%	No light $\rightarrow$ Full orange					
7		Orange	0	65535	0.0%	100.0%	Orange, fine (LSB)	0(0%)				
8	5		0	255	0.0%	100.0%	No light $ ightarrow$ Full amber	0(00()				
9		Amber	0	65535	0.0%	100.0%	Amber, fine (LSB)	0(0%)				
10	6	Graan	0	255	0.0%	100.0%	No light $ ightarrow$ Full green	0(0%)				
11		Green	0	65535	0.0%	100.0%	Green, fine (LSB)	0(0%)				
12	7	Guan	0	255	0.0%	100.0%	No light $ ightarrow$ Full cyan	0(0%)				
13		Cyan	0	65535	0.0%	100.0%	Cyan, fine (LSB)	0(0%)				
14	8	Blue	0	255	0.0%	100.0%	No light $\rightarrow$ Full blue	0(0%)				
15		ыце	0	65535	0.0%	100.0%	Blue, fine (LSB)	0(0%)				
16	9	Indigo	0	255	0.0%	100.0%	No light $\rightarrow$ Full indigo	0(0%)				
17		indigo	0	65535	0.0%	100.0%	Indigo, fine (LSB)	0(0%)				
18	10	White	0	255	0.0%	100.0%	No light $\rightarrow$ Full white	0(0%)				
19		wille	0	65535	0.0%	100.0%	White, fine (LSB)	0(0%)				



DMX	mode					<b>N</b> 4 1/		Default	1
Standard	Basic	Name	DM	K value		MX	Function	DMX	
(21ch)	(12ch)				perce	entage		Value	
			0	24	0.0%	9.4%	No function		
			25	35	9.8%	13.7%	3200К		
			36	46	14.1%	18.0%	3400K		
			47	57	18.4%	22.4%	3600K		
			58	68	22.7%	26.7%	3800K		
			69	79	27.1%	31.0%	4000K		
			80	90	31.4%	35.3%	4200K		
			91	101	35.7%	39.6%	4400K		
			102	112	40.0%	43.9%	4600K		
			113	123	44.3%	48.2%	4800K		
20	11	Color temperature	124	134	48.6%	52.5%	5000K	0(0%)	
20		color temperature	135	145	52.9%	56.9%	5200K	0(070)	
			146	156	57.3%	61.2%	5400K		
			157	167	61.6%	65.5%	5600K		
			168	178	65.9%	69.8%	5800K		
			179	189	70.2%	74.1%	6000K		
			190	200	74.5%	78.4%	6200K		
			201	211	78.8%	82.7%	6400K		
			212	222	83.1%	87.1%	6600K		
			223	233	87.5%	91.4%	6800K		
			234	244	91.8%	95.7%	7000K		
			245	255	96.1%	100.0%	7200K		
			0	39	0.0%	15.3%	No function		
			40	59	15.7%	23.1%	Built-in program 1		
			60	79	23.5%	31.0%	Built-in program 2		
			80	99	31.4%	38.8%	Built-in program 3		
			100	119	39.2%	46.7%	Built-in program 4		
21	12	Special controls	120	139	47.1%	54.5%	Built-in program 5	0(0%)	
21	12	Special controls	140	159	54.9%	62.4%	Built-in program 6	0(0%)	
			160	179	62.7%	70.2%	Built-in program 7		
			180	199	70.6%	78.0%	Built-in program 8		
			200	219	78.4%	85.9%	Built-in program 9		
			220	239	86.3%	93.7%	Built-in program 10		
			240	255	94.1%	100.0%	No function		

## ▲ Notes

Do not switch off the fixture within the first minute after switching on. Wait for at least 5 minutes to switch on the fixture.



## **Technical specification**

#### Optical

- Light source: LED 3W, quantity: 100pcs (12R+12OR+12A+14G+14CY+12B+12IN+12W)
- Expected average lifetime: 50000 hours
- Beam angle (fixed): Pan: 72°, tilt: 60° (10% peak angle)
- 8 colors liner mixing, each ring of LEDs individually controllable

#### Photometric

- Total Output (Lumen): 10400 lumens
- Color temperature: 3200K-7200K linear regulation

#### Electrical

- Power input, nominal: AC 100-240V, 50/60Hz
- Max. Power consumption: 300W, max current: 3A, PF≥ 0.98
- Power supply unit: Auto-ranging electronic SMPS
- Main fuse: 250V/3.15A

#### **Control and programming**

- Control channels (DMX): 21/12
- Protocol: DMX-512
- Display: 4 x 8 segment display
- 16-bit control: Dimmer

#### **Physical / Installation**

- Weight: 8kg (17.6 lbs.)
- IP rating: IP20
- Material: Aluminum, steel, plastic
- Mounting points: 12mm holes for G-Clamp
- Minimum distance to combustible materials: 1.64ft. (0.5m)
- Minimum distance to illuminated surfaces: 3.28ft. (1m)

#### Dynamic effects

- Pan/Tilt movement: Manually adjustable
- Strobe: 1-25Hz, synchronized, pulse effects
- Dimmer: 0-100%, 16-bit, electronic linear dimming

#### Thermal

- Operating range: 14°F to 113°F (-10°C to +45°C)
- Startup range: 5°F to 113°F (-15°C to +45°C)
- Storage range: -40°F to 140°F (-40°C to +60°C)
- Cooling: Passive



#### • Humidity: ≤85%

#### Connections

- AC power: Neutrik powerCon
- DMX data input/output: Chassis 5-pin Neutrik XLR (in/out)


#### **Certification and Safety**

- EMC: EN 55103-1:2009, EN 55103-2:2009, EN 61000-3-2:2006+A2:2009, EN 61000-3-3:2013
- Safety: EN 60598-2-17:1989/A2:1991

#### Photometric

Pan angle:  $72^{\circ}$ 

Tilt angle:  $60^{\circ}$ 



## **Cleaning and maintenance**

It is required that the fixture should be kept clean and well maintained to ensure its reliability. Its lifespan mainly depends on the working environment and proper operation. Should you have any questions, please consult a technical engineer of GTD Lighting.

### ▲Notes

Damage resulted from dust, smoke, oil or improper use is not covered by warranty.

### Warning

Disconnect the fixture from AC power, and let it cool down for at least 15 minutes before opening the housing. Make sure to use a soft cloth to clean the optical components, and be careful, as the coating is easily scratched. Do not use any organic solvent such as alcohol to clean the reflector mirror, dichroic color filters or housing of the fixture.




- If the lens is cracked or otherwise damaged, replace it immediately.
- If the LED lamp becomes damaged or deformed in any way it must be replaced.
- If the light from the LED lamp appears dim, this normally indicates that it is reaching the end of its life span and should be changed at once. Aged LED lamps run to the extremity of their life might explode.
- If fixture does not function, check the fuse on the power socket of the fixture. Replace the fuse of the same specification if it is blown.
- The fixture is equipped with thermal-protection device that will switch off the LED lamp in case of overheating. If this happens, please check that the fans are not blocked, and clean them if they are dirty. Check whether the fans are operational. If not, call a qualified technician. Troubleshoot and correct the problem before switching on the fixture again. Any maintenance work should only be carried out by qualified technicians.

## Troubleshooting

Problem	Possible Cause	Suggested Correction				
	Power switch not turned on.	Turn on power switch.				
No response	Take out the fuse and check if it is blown.	Locate the blown fuse. Remove the broken fuse. Insert a replacement fuse of the correct amperage.				
after connected to A/C power	Abnormal A/C input (A/C power socket, power cables, luminaire power socket).	Replace AC power socket and power cables, and then adjust power socket for proper connection.				
	No DC voltage from switching power supply.	Check if the switching power supply has DC voltage output. Replace the switching power supply.				
	DMX cables disconnected from fixture's DATA IN connector.	Connect DMX cable to the fixture's DATA IN connector.				
No response or	Open circuit or short circuit fault in the DMX cables.	Replace DMX cables as required.				
wrong response to the	Wrong DMX address for the fixture in the control system.	Ensure the address in "Run setting > Address Setting > Address" of the fixture is consistent with the address in the control system.				
commands of the control system	Misuse in "Channel setting > Channel Mode" of the fixture.	Choose the channel mode in "Channel setting > Channel Mode" of the fixture as required by the user.				
	Malfunctioning of DMX cannon input /output connectors. No input/output voltage to the main control board of the fixture.	Troubleshooting the DMX XLR signal plate of the fixture, replace the main control board of the fixture.				
	There is no signal output to the main control board PWM.	Replace the main control board or repair.				
LED lamp off	No output to the drive board LED +/ LED- or drive board over-current, check line connector if contact bad.	Reconnect the terminal, replace the driver board				
	Normal end of LED lamp life, bad welding or poor heat dispersion.	Repair or replace LED light source or replace the whole piece of aluminum board, remove the cooling system failure.				
Decreased	LED lamp aging, check the service time of LED light source, test LED drive board's current.	Replace the LED light source or adjust the drive board's current. Reduce LED's brightness.				
brightness, uneven pattern projections	Excessive dusts or smudges on the effect assembly, focus module and objective lens.	Follow the instructions stated in this user manual to clean the effect assembly, focus module and objective lens.				
	Damaged or deformed effect assembly, focus module or objective lens.	Replace the damaged or deformed components.				



## System wiring diagram








## Spare parts list

Item	P/N	Qty	Notes
LED aluminum substrate	5802010033A	2	LIB0304D
LED driver board	5802030037A	1	LCR0305D
Display board	5809210026B	1	L3100-101E11&102F11&103F11 SDI0200B
XLR board	5802910008A	1	SKL0006B
Switching power supply	1412050023A	1	EDS350-5628PN 350W EAGL

## Appendix 1









Notes:

P/N: 1502011034A Time: May 15<sup>th</sup>, 2017